

www.alcatelonetouch.com

For more information on how to use the phone, please go to www.alcatelonetouch.com and download the complete user manual. Moreover, on the website, you can also find answers to frequently asked questions, and so much more.

ALCATEL **onetouch**.



ALCATEL **onetouch**.

Table of contents

Safety and use.....	4
General information	12
1 Getting started.....	14
1.1 Set-up	14
1.2 Power on your phone.....	16
1.3 Power off your phone.....	16
2 Your mobile.....	17
2.1 Keys	18
2.2 Main screen icons	20
3 Calls.....	22
3.1 Making a call.....	22
3.2 Calling your voicemail	22
3.3 Receiving a call.....	23
3.4 During a call	23
4 Contacts.....	25
4.1 Consulting your contacts	25
4.2 Adding a contact.....	25
4.3 Available options.....	26
5 Messages	27
5.1 Access	27
5.2 Create message.....	27
5.3 Voicemail.....	27
5.4 Broadcast SMS	28
5.5 Settings.....	28
5.6 Empty folder	28

6 Images.....	29
7 WAP.....	29
7.1 Homepage	29
7.2 Bookmarks	29
7.3 Recent pages.....	29
7.4 Go to URL	29
7.5 Settings.....	29
8 Camera	30
8.1 Take a photo, save or delete	30
8.2 Settings in framing mode	31
8.3 Options available after taking the photo	31
9 Music.....	32
9.1 Music playing mode.....	32
9.2 Settings.....	33
10 FM radio.....	34
11 Settings	35
11.1 Tri SIM settings	35
11.2 Phone settings	35
11.3 Call settings.....	37
11.4 Security	40
11.5 Network.....	40
11.6 Connectivity.....	41
12 Call log	42
12.1 Access	42
12.2 Available options.....	42

13 Alarm	43
14 Calendar	44
15 Calculator	44
16 Profiles	45
16.1 General	45
16.2 Vibrate	46
16.3 Silent	46
16.4 Flight mode	46
17 My files	47
17.1 Memory card	47
17.2 Managing audios, images, and others	48
17.3 Formats and compatibility	48
18 Services	48
19 Latin input mode	49
20 Telephone warranty	50
21 Accessories	52
22 Troubleshooting	53



www.sar-tick.com

This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 7 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 10 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

Safety and use.....

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

• TRAFFIC SAFETY:

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their mobile when the vehicle is not parked.

When driving, do not use your phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your phone on top of the dashboard or within an airbag deployment area,
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.

• CONDITIONS OF USE:

You are advised to switch off the telephone from time to time to optimise its performance.

Switch the phone off before boarding an aircraft.

Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile telephones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere.

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage.

Do not let children use the phone and/or play with the telephone and accessories without supervision.

When replacing the cover please note that your phone may contain substances that could create an allergic reaction.

Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating temperature range is -10°C to +55°C.

At over 55°C the legibility of the phone's display may be impaired, though this is temporary and not serious.

Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourself.

Do not drop, throw or bend your mobile phone.

Do not paint it.

Use only batteries, battery chargers, and accessories which are recommended by TCT Mobile Limited and its affiliates and are compatible with your phone model (see Accessories List, page 52). TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Remember to make back-up copies or keep a written record of all important information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.

Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

• PRIVACY:

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your mobile phone regarding taking photographs and recording sounds with your mobile telephone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorisation be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your mobile phone (including the operator) disclaim any liability which may result from the improper use of the mobile phone.

• BATTERY:

Before removing the battery from your phone, please make sure that the phone is switched off.

Observe the following precautions for battery use:

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery,
- Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60°C.

Batteries must be disposed of in accordance with locally applicable environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates.



This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centres with specific bins for these items of equipment
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

• CHARGERS

Mains powered chargers will operate within the temperature range of: 0°C to 40°C.

The chargers designed for your mobile phone meet with the standard for safety of information technology equipment and office equipment use. They are also compliant to the ecodesign directive 2009/125/EC. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

• RADIO WAVES:

Proof of compliance with international standards (ICNIRP) or with European Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards or this directive.

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg.

Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are:

3000G:

Maximum SAR for this model and conditions under which it was recorded.		
Head SAR	GSM 900	0.991 W/kg
Body-worn SAR	GSM 900	1.03 W/kg

3000H:

Maximum SAR for this model and conditions under which it was recorded.		
Head SAR	GSM 900	0.991 W/kg
Body-worn SAR	GSM 900	1.03 W/kg

During use, the actual SAR values for this device are usually well below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out at a separation distance of 10 mm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body. If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the phone the indicated distance away from the body.

Organizations such as the World Health Organization and the US Food and Drug Administration have stated that if people are concerned and want to reduce their exposure they could use a hands-free device to keep the phone away from the head and body during phone calls, or reduce the amount of time spent on the phone.

For more information you can go to www.alcatelonetouch.com

Additional information about electromagnetic fields and public health are available on the following site: <http://www.who.int/peh-emf>.

Your telephone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 10 mm away from the body.

• Regulatory information

The following approvals and notices apply in specific regions as noted.

3000G:

TCT Mobile

TCT Mobile Europe SAS
55 Avenue des Champs Plerieux,
Immeuble Le Capilote 92000 Nanterre, France
+33 1 46 52 61 00

EC declaration of conformity / Déclaration de conformité CE
GSM quad bands handheld station with FM radio / Portail GSM quadbandes avec technologie radio FM

Product Identification / Identification du produit :
ALCATEL 3000G type Tigris 151M

We / Nous TCT Mobile Europe SAS
55, avenue des Champs Plerieux
92000 Nanterre
France

Declare under our sole responsibility that the product above mentioned is conform to the applicable essential requirements of the directive 1999/5/EC and that all essential radio test suites have been carried out. Conformity assessment procedure : annex IV of the directive. / déclarons sous notre entière responsabilité que le produit ci-dessus est en conformité avec les exigences essentielles applicables de la directive 1999/5/CE et que toutes les séries d'essais radio essentielles ont été effectuées. Procédure d'évaluation de conformité : annexe IV de la directive.

Applied standards / Normes appliquées :

- Item 3.1.a (protection of the health and of the safety of the user) / Article 3.1.a (protection de la santé et de la sécurité de l'utilisateur)
 - EN 60950-1:2006 + A11:2009+ A12:2011 + A1:2010
 - EN 62209-1 (2009)
 - EN 62209-2 (2010)
 - EN 50 360: 2001/AC:2006, Council recommendation 1999/519/EC (July 99)
- Item 3.1.b (protection requirements with respect to electromagnetic compatibility) / Article 3.1.b (exigences de protection en ce qui concerne la compatibilité électromagnétique)
 - EN 301 489-1 v.1.9.2 (2011-09), EN 301 489-7 v.1.3.1 (2005-11),
- Item 3.2 (effective use of spectrum so as to avoid harmful interferences) / Article 3.2 (utilisation efficace du spectre radioélectrique de façon à éviter les interférences dommageables)
 - EN 301 511 v.9.0.2 (2003-03),

This product also conforms to the applicable requirements of following directives,
- directive 2004/108/EC (electromagnetic compatibility). / Ce produit est en conformité avec la directive 2004/108/CE (compatibilité électromagnétique)
- EN 55013:2001 + A2:2006
- EN 55020:2007
- directive 2011/65/EU (RoHS - restriction of the use of certain hazardous substances)

This product can connect with a Common Mobile Phone Charger which complies with below standards: (Ce produit peut être utilisé avec un chargeur universel pour téléphone portable conforme aux standards suivants :

- EN301 489-34 v1.3.1 (2012-05)
- EN301 489-34 v1.1.1 (2010-10)
- EN 62684:2010

Conformity of this product has been reviewed by the following Notified body of directive 1999/5/EC / La conformité de ce produit a été vérifiée par l'organisme de certification (notifi body) suivant.
American Certification Body, Inc.
Suite C110, Whittier Avenue 6731, 22101 McLean, Virginia, United States
Identification number: 1588

Date :2013-05-29

Signature

TCT Mobile Europe SAS / Deputy General Manager, EMEA

CE1588

3000H:

TCT Mobile

TCT Mobile Europe SAS
55 Avenue des Champs Plerieux,
Immeuble Le Capilote 92000 Nanterre, France
+33 1 46 52 61 00

EC declaration of conformity / Déclaration de conformité CE
GSM quad bands handheld station with FM radio / Portail GSM quadbandes avec technologie radio FM

Product Identification / Identification du produit :
ALCATEL 3000H type Tigris 351M

We / Nous TCT Mobile Europe SAS
55, avenue des Champs Plerieux
92000 Nanterre
France

Declare under our sole responsibility that the product above mentioned is conform to the applicable essential requirements of the directive 1999/5/EC and that all essential radio test suites have been carried out. Conformity assessment procedure : annex IV of the directive. / déclarons sous notre entière responsabilité que le produit ci-dessus est en conformité avec les exigences essentielles applicables de la directive 1999/5/CE et que toutes les séries d'essais radio essentielles ont été effectuées. Procédure d'évaluation de conformité : annexe IV de la directive.

Applied standards / Normes appliquées :

- Item 3.1.a (protection of the health and of the safety of the user) / Article 3.1.a (protection de la santé et de la sécurité de l'utilisateur)
 - EN 60950-1:2006 + A11:2009+ A12:2011 + A1:2010
 - EN 62209-1 (2009)
 - EN 62209-2 (2010)
 - EN 50 360: 2001/AC:2006, Council recommendation 1999/519/EC (July 99)
- Item 3.1.b (protection requirements with respect to electromagnetic compatibility) / Article 3.1.b (exigences de protection en ce qui concerne la compatibilité électromagnétique)
 - EN 301 489-1 v.1.9.2 (2011-09), EN 301 489-7 v.1.3.1 (2005-11),
- Item 3.2 (effective use of spectrum so as to avoid harmful interferences) / Article 3.2 (utilisation efficace du spectre radioélectrique de façon à éviter les interférences dommageables)
 - EN 301 511 v.9.0.2 (2003-03),

This product also conforms to the applicable requirements of following directives,
- directive 2004/108/EC (electromagnetic compatibility). / Ce produit est en conformité avec la directive 2004/108/CE (compatibilité électromagnétique)
- EN 55013:2001 + A2:2006
- EN 55020:2007
- directive 2011/65/EU (RoHS - restriction of the use of certain hazardous substances)

This product can connect with a Common Mobile Phone Charger which complies with below standards: (Ce produit peut être utilisé avec un chargeur universel pour téléphone portable conforme aux standards suivants :

- EN301 489-34 v1.3.1 (2012-05)
- EN301 489-34 v1.1.1 (2010-10)
- EN 62684:2010

Conformity of this product has been reviewed by the following Notified body of directive 1999/5/EC / La conformité de ce produit a été vérifiée par l'organisme de certification (notifi body) suivant.
American Certification Body, Inc.
Suite C110, Whittier Avenue 6731, 22101 McLean, Virginia, United States
Identification number: 1588

Date :2013-05-29

Signature

TCT Mobile Europe SAS / Deputy General Manager, EMEA
Champs Plerieux - FRANCE
Nanterre 92000 440 038 222

CE1588


• LICENCES

Obigo®

is a registered trademark of Obigo AB.



microSD Logo is a trademark.

 eZiText™
Zi corporation

eZiText™ and Zi™ are trademarks of Zi Corporation and/or its Affiliates.

General information

- **Internet address:** www.alcatelonetouch.com
- **Hot Line Number:** see "TCT Mobile Services" leaflet or go to our Internet site.
- **Address:** Room 1910-12A, Tower 3, China HK City, 33 Canton Road, Tsimshatsui, Kowloon, Hong Kong

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

An electronic version of this user guide is available in English and other languages according to availability on our server:

www.alcatelonetouch.com

Your telephone is a transceiver that operates on GSM networks with 850/900/1800/1900 MHz bands.

CEI588

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of the Declaration of Conformity for your telephone can be obtained through our website: www.alcatelonetouch.com

Protection against theft ⁽¹⁾

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0 6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.


TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

⁽¹⁾ Contact your network operator to check service availability.


Getting started

1.1 Set-up


Removing and installing the back cover



Removing and installing the battery




Removing and inserting the SIM card ⁽¹⁾



⁽¹⁾ Check with your network operator to make sure that your SIM card is 3V or 1.8V compatible. The old 5 Volt cards can no longer be used. Please contact your operator.

3000H




Place the SIM card with the chip facing downwards/upwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

Charging the battery ⁽¹⁾



Connect the battery charger to your phone and mains socket respectively.


- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.

⁽¹⁾ Depending on your country.




The charge is complete when the animation stops.

1.2 Power on your phone

Hold down the  key until the telephone powers on, type in your PIN code if necessary and then confirm. The main screen is displayed.

If you do not know your PIN code or if you have forgotten it, contact your network operator. Do not leave your PIN code with your telephone. Store this information in a safe place when not in use.

If cell broadcast messages are displayed, you can browse through them or press  to return to the main screen.

While the phone is searching for a network, "**Searching/Emergency**" will be displayed.


In the power on screen, you also have access to the functions of "**FM radio**", "**Camera**"⁽¹⁾, "**Music**"⁽¹⁾, etc. even if there is no SIM card inserted.

1.3 Power off your phone

Hold down the  key from the main screen.

⁽¹⁾ Make sure that MicroSD card is well inserted.

2 Your mobile



- 1 Navigation key:
Menu/Confirm an option
- 2 Left softkey
- 3 Pick up/Send call
Call log (Idle screen)
- 4 Vibration alert
(press and hold)
- 5 Fn key
- 6 Right softkey
- 7 Switch on/
Switch off
End call

2.1 Keys



Navigation key
Confirm an option (press the middle of the key)



Pick up
Send a call
In idle screen:
Access call log (Redial) (press)



Switch on/Switch off the telephone (press and hold)
End call
Return to idle screen



Left softkey



Right softkey



Access your voicemail (press and hold)



In idle screen:
Press and hold: Lock the keypad
In edit mode:
Press: input space
Press and hold: switch language

Fn

In idle screen:

Press to access shortcuts

Fn + P: Access to Profiles

Fn + S: Access to Settings

In edit mode:

Press once: Input a top-half character

Press twice: Lock the keyboard in top-half key input mode, then press again to unlock top-half character input mode



Delete one by one (press)

Delete one by one quickly (press and hold)



Move cursor to the next line



In edit screen:

Press: Switch the uppercase and lowercase

2.2 Main screen icons ⁽¹⁾

In 3000G:



Battery charge level.



Vibrate alert: your phone vibrates, but does not ring or beep (see page 46).



Headset connected.



Keypad locked.



Call forwarding activated: your calls are forwarded (see page 38).



Alarm programmed (see page 43).



Level of network reception.



Voicemail message arrived.



Missed calls.



Radio is on.



Roaming.









SIM card missing.






SD card scanning completed.

⁽¹⁾ The icons and illustrations in this guide are provided for information purposes only.



-  **GPRS connection status** (Activated).
-  **GPRS connecting.**
-  **Silence mode:** your phone does not ring, beep or vibrate (see page 46).
-  **SMS unread.**
-  **Music activated.**
-  **Flight mode.**

In 3000H:

-  **Level of network reception.**
-  **GPRS connection status** (Activated).
-  **GPRS connecting.**


3 Calls.....

3.1 Making a call


Dial the desired number then press the  key to place the call. For triple SIM model, you can select any of your SIM cards when you wish to place a call ⁽¹⁾. If you make a mistake, you can delete the incorrect digits by pressing the  key.

To hang up the call, press the  key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the  key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail ⁽²⁾

Your voicemail is provided by your network to avoid missing calls. It works like an answering machine that you can consult at any time. To access your voicemail, hold down the  key.

If the access number for your operator's voicemail service does not work, dial the number that you were given. To change this number, refer to "Voicemail" (see page 37).






To use your voicemail service from abroad, contact your network operator before leaving.

⁽¹⁾ 3000H only.

⁽²⁾ Contact your network operator to check service availability.

3.3 Receiving a call

When you receive an incoming call, press the  key to talk and then hang up using the  key.

If the  icon is displayed, the vibrator is activated and there is no ringtone.

If the  icon is displayed, the phone neither rings nor vibrates.



The caller's number is displayed if it is transmitted by the network (contact your network operator to check service availability).

Muting the ringtone

You may mute ringtone of current incoming call by pressing .

Answer the call by pressing the  key.

Rejecting a call

Press the  key once to reject the call.

3.4 During a call ⁽¹⁾

Available functions

During a call, you can use your contacts, short messages, etc. without losing your correspondent.

WARNING: move the handset away from your ear while turn on the speaker because the amplified volume might cause hearing damage.

Adjusting the volume

You can adjust the sound level during a call using the up/down key.

Handling two calls

- Answering a second call (ensure that "**Call waiting**" is activated, see page 38).
- To call a second party during a call, you may press "**Options**" and select "**New call**".

⁽¹⁾ Contact your network operator to check service availability.

4 Contacts

4.1 Consulting your contacts

To access the contacts from the main screen, press the  key and select the  icon from the menu.

For triple SIM model, the complete contacts of all SIM cards are available in this menu ⁽¹⁾.

Searching for a contact

You can search for a contact by inputting the initial of their name. Subsequent letters may be added to refine the search. Or you may scroll up/down to find the contact you need when reaches the initial letter among contact list part (A-Z).

Viewing a contact

Select a name from your contacts to read the contact information. Select **"Options"** to send messages, edit the contact, etc.

4.2 Adding a contact

You can add a new contact to phone or SIM card by selecting **"Add contact"**.

Following fields are accessible when you create a new contact in the contacts: Name, Number, Note, etc.

You can move from one field to another by scrolling up and down.



If you use your phone abroad, store the numbers in your contacts in international format **"+"** followed by the country code.

⁽¹⁾ 3000H only.

4.3 Available options

From the list of names, you can access the following options:

Send message	Send an SMS to a contact you selected from the directory.
Edit	Modify the contents of the contact: name, number, note, etc.
Edit before call	Edit the phone number before placing a call.
Delete	Delete the selected contact.
Copy to SIM	Copy the selected contact to SIM.
Multi- mark	Mark/Unmark a tick on a contact for further operation.
Settings	
Display mode	You may view contacts stored in phone only, SIM only or both in SIM and phone.
My number	Type in or modify user's own name, number.
Copy all	Copy all contacts to phone or SIM card.
Memory status	View used and available space in phone and SIM card.

5 Messages

You can create, edit and receive SMS with this mobile phone.

5.1 Access

You may access this menu using the following options:

- Press  to enter the main menu screen, and then select .

You may have access to the following folders: **Create SMS, Inbox, Outbox, Sent, Drafts, Voicemail, Broadcast messages, Empty folder, Templates, Settings.**

5.2 Create message

From the main menu select "**Messages**" to create text message. You can type a message and you can also modify a predefined message in **Templates**. While writing a message, select "**Options**" to access all the messaging options.



Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

5.3 Voicemail

View and edit the voicemail number.

5.4 Broadcast SMS ⁽¹⁾

Store the received Broadcast SMS.

Receive mode	Enable to receive broadcast SMS.
Channel setting	Select/Add/Edit/Delete channels.
Languages	Language selection.
Read message	Enable to read.

5.5 Settings

Text messages

SIM	You can set validity period, message type, sent on/off, reply path, etc.
Save sent message	Select " on " or " off " options for messages.
Memory status	Memory used on the phone.
Pref. storage	Select default message storage, SIM or phone.

5.6 Empty folder

You may delete all threads with this option.

⁽¹⁾ Depending on your network operator.

6 Images.....

A library links to the images in memory card to be set as Wallpaper, Power on/off display.

7 WAP

Make sure that microSD card is well inserted before accessing this feature.

7.1 Homepage

Launch the WAP browser with the preset homepage.

7.2 Bookmarks

Access your favourite sites.

7.3 Recent pages

Pages which you recently browsed.

7.4 Go to URL

Enter the URL of Wap site.

7.5 Settings

Customise your browser preferences.



8 Camera.....

Your mobile phone is fitted with a camera for taking photos that you can use in different ways:

- store them in your **"My files\Images"**.
- customise your main screen (see page 35).

Make sure that microSD card is well inserted before taking photos.

8.1 Take a photo, save or delete

The screen acts as the viewfinder. Position the object or landscape in the viewfinder and press  to take the image and the images will be automatically saved. If you don't want it, you may directly delete it by pressing .

8.2 Settings in framing mode

Before taking the photo, you can adjust a number of settings by using the following shortcuts:

From the photo shot screen, press **"Options"** to access: **"My images"**, **"Image size"**, **"Quality"**, **"Night mode"**, **"Banding"**, **"White balance"**, **"Restore default"**.

Press  to access My images to view the photos you have taken.

	My images		Banding
	Image size		White balance
	Quality		Restore default
	Night mode		

8.3 Options available after taking the photo

Once you have taken a photo, you can choose to Set as wallpaper, Power on/off.

9 Music



Access this feature from the main menu by selecting **"Music"**.

You will have full flexibility of managing music on memory card.

Make sure that microSD card is well inserted before activating music.

9.1 Music playing mode



9.2 Settings

List Auto generate	On	The list of songs will be refreshed every time you insert SD card.
	Off	The list of songs will not be refreshed every time you insert SD card.
Repeat		You can set to repeat one, repeat all or not to repeat.
Shuffle		It can be set to play randomly or not.
Play as background		When you choose to play music as background, you can still run other applications.

10 FM radio.....

Your phone is equipped with a radio ⁽¹⁾ with RDS ⁽²⁾ functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.


Available options:

Channel list	Open the list of saved stations.
Save channel	Save the current tuned station to the " Channel list ".
Auto search	Start auto search and stations will be automatically saved to " Channel list ".
Enter frequency	Enter the frequency manually.
Settings	Scroll up and down to manage settings.
Exit	Stop playing the radio.

⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.

⁽²⁾ Depending on your network operator and market.

Settings.....

From the main menu, select the menu icon  and select the function of your choice in order to customise your telephone.

11.1 Tri SIM settings ⁽¹⁾

Three SIM activated Keep all of your SIM cards active.

Only SIM1 activated Only keep SIM1 active.

Only SIM2 activated Only keep SIM2 active.

Only SIM3 activated Only keep SIM3 active.

11.2 Phone settings

11.2.1 Time and date

Allows you to have settings of date and time, including 12/24h format.

You can also set the daylight saving adjustment.

11.2.2 Display

Wallpaper

The wallpaper is displayed when you switch on your telephone.

By selecting "**Wallpaper**" you can customise it by replacing the default image or animation displayed on your telephone.

⁽¹⁾ 3000H only.

Power On/Off ⁽¹⁾

You can customise your welcome animation or image that appears when you switch on your phone.

You can also customise your OFF screen with an image or animation.

Brightness

You may adjust black level with respect to LCD display by pressing ◀▶ key.

Backlight

Allows you to reduce brightness for enhanced battery performance and to save power during periods of expected inactivity.

You may customise your keypad light by selecting **5s/10s/30s/1min/2mins/5mins/10mins**.

11.2.3 Languages ⁽²⁾

Display language for messages (select using ◀▶). The "**Auto**" option selects the language according to the home network (if available).

⁽¹⁾ Depending on the model.

⁽²⁾ Contact your network operator to check service availability.

11.2.4 Headset mode

Switch audio play (incoming call, message beep, alarm beep...) between **Headset only** and **Phone and Headset**.

11.2.5 Keypad

By customising your keypad, you can access any function directly from the idle screen.

11.2.6 Auto keylock

Your keypad will be locked automatically, you can set the auto lock time.

Unlock the keypad

To unlock the keypad, you may press "**Unlock**".

11.2.7 Input mode

Please see chapter "**Latin input mode**", page 49. In addition to the specific characters table for Cyrillic, Chinese, other data input modes are also available in your telephone. This feature allows you to write short messages and add names with special characters to your directory.

11.3 Call settings

You can access a number of items with this option:

11.3.1 Voicemail

Dial or edit your voicemail.

11.3.2 Billing ⁽¹⁾

You can access different items with this option:

Amount

You can view the total cost of charged calls, modify it or reset it and enter the cost of a call in the currency of your choice.

Duration


You can view the total duration of all outgoing calls, Answered calls or reset it.

11.3.3 Call waiting

Activate/deactivate the notification of a second incoming call by a beep.

11.3.4 Call forwarding

You can activate, cancel or verify the status of the call forwarding to the voicemail or to a specified number. The following configurations are possible:

- Unconditional: systematic forwarding of all your calls. The  icon is displayed.
- Conditional: if your line is busy, if you don't answer or if you are outside the network range.

⁽¹⁾ Contact your network operator to check service availability.

11.3.5 Call barring

You can activate or deactivate the call barring for outgoing and incoming calls. The various options are:

Outgoing calls

The following configurations are possible:

- **All calls** All outgoing calls are barred.
- **International calls** Outgoing international calls are barred.
- **International except home** Outgoing international calls except those to your country of subscription are barred.

Incoming calls

The following configurations are possible:

- **All calls** All incoming calls are barred.
- **Roaming** Incoming calls are barred when you are abroad.

Cancel all

Deactivate all call barring.

Change barring Password

Change the original Password for activating call barring.

11.3.6 Caller ID

Activate/deactivate CLIR.

11.3.7 Auto redial

You can activate or deactivate the automatic callback of your party for calls that do not get through the first time

11.4 Security

Activate PIN

The SIM card protection code is requested each time the phone is powered on if this code is activated.

Change PIN

Change PIN code.

Change PIN2

A protection code for certain SIM card features (Billing/Cost/FDN, etc.) will be requested if you attempt to access it, if the code is activated. Select to update it with a new one (between 4 and 8 digits).

Activate phone code

Code is requested each time the phone is powered on.

Change password

Change phone password, its initial one is 1234.

Fixed dialed number

Allows the phone to be "locked" so that it can only dial certain numbers, or numbers with certain prefixes. To activate this function, PIN2 code is mandatory.

11.5 Network

Network selection

Preferred network

List of networks to which you wish to be connected in order of priority.

Select network

The choice of network connection is left up to the user.

Search mode

Network connection can be switched between "Manual" and "Auto".

GPRS connection ⁽¹⁾

When needed	GPRS mode active depending on connection requirements.
Always	GPRS mode continuously active.
GPRS international roaming	GPRS data services can be used while roaming overseas.


11.6 Connectivity

A set of profile settings for WAP connection.




⁽¹⁾ 3000G only. Depending on network availability.

12 Call log.....

12.1 Access

You can access your call memory by pressing  from the idle screen, and you will see **Outgoing call(s)**, **Missed call(s)** and **Answered call(s)**.

For triple SIM model, the complete call logs of all SIM cards are available in this menu ⁽¹⁾.

-  Missed calls
-  Outgoing calls
-  Incoming calls

12.2 Available options

When you press "**Options**", you may have access to **Send message**, **Edit before call**, **Delete**, **Delete all**, etc.

⁽¹⁾ 3000H only.

3 Alarm.....



Your mobile phone has a built-in alarm clock with a snooze feature. You can set up to five separate alarms and choose whether or not the alarm should repeat.

- Repeat** You may select **Once** (default)/**Every day/Days (Mon-Fri)**.
- Snooze** The alarm will repeat at regular intervals.
- Alert type** You may select the type of alert: **Vibration and ring, Ring only or Vibration only**.
- Ringtone** You may choose one melody as the alarm ringtone.

4 Calendar.....



Once you enter this menu from the main menu, there is a monthly-view calendar for you to view.

Available options:

- Jump to date** Input the required date and it will be immediately highlighted.
- Go to today** Focus on today's date.
- First day of one week** You can set Sunday or Monday as the first day of one week.

5 Calculator.....




Enter a number, select the type of operation to be performed, and enter the second number, then press "=" to display the result.

16 Profiles.....

With this menu, you may personalise ringtones for different events and environments.

16.1 General

To modify the sound settings within any profile, press "**Options**" and select "**Customize**" and you will see the functions below by scrolling up/down Volume key:

Ringtone	Select a melody from the list by scrolling up and down the Volume key then confirm by pressing " Options\Select ".
Alert type	You may set your phone ringtone to Ring only, Vibration only (all sounds are replaced by vibrations except for alarms), Vibration and ring, Vibration then ring, Silence (no sounds except for alarms, the  icon will be displayed).
Ringtone volume	Adjust the volume using the up/down key.
Keypad	Select the type of key beep.
Message tone	Select a melody for a new incoming message.
Ring type	Set your ring type to Ascending, Beep once, Repeat.
Power On	Select a Power on melody for your phone.
Power Off	Select a Power off melody for your phone.

16.2 Vibrate

When this is selected the phone will not ring unless an alarm has been set.

16.3 Silent

This profile will turn off all ringtones, including notification sounds.

16.4 Flight mode

Voice calls and messaging functions are barred. Can be used to increase standby duration.

17 My files.....



You will have access to all audio and visual files stored in memory card in **My files**.


17.1 Memory card

You can access all files stored in the memory card here.



When a memory card is inserted for the first time, it will be scanned and default folders will be created.

Inserting and removing the memory card:



To release the microSD card holder, slide it in the direction of the arrow and lift it. Then insert the microSD card with the golden contact downward. Finally, turn down the microSD holder and slide it in the opposite direction to lock it.



Do not support hot plugging for microSD card.

17.2 Managing audios, images, and others

According to the item chosen, you can access some of the functions below:

View	View the selected image.
Play	Play the selected video/audios.
Delete	Delete the audio/image/video selected (not applicable for embedded items).
Set as	Sound→ringtone
Rename	Rename the audio/image/video.
Move	Move a file to other folders.
Copy	Copy a file to other folders.

17.3 Formats and compatibility ⁽¹⁾

- Sounds: Midi, SP-Midi, AMR, WAV, MP3
- Images: jpg, gif, bmp

18 Services




Contact your network operator to check service availability.

⁽¹⁾ Depending on phone and market.


19 Latin input mode.....


To write messages, there are two writing methods ⁽¹⁾:

- Normal (for English): this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.
- Predictive with the Zi mode (for other languages): This mode speeds up the writing of your text.

Fn key  :
Press once: input a top-half character
Press twice: Lock the keyboard in top-half key input mode, then press again to unlock tophalf character input mode

Space key  :
Press: input space
Press and hold: switch language
Fn+Space: switch input mode

Shift key  :
In abc (Multitapabc) input mode:
Press once: only switch one character from minuscule to uppercase
Press twice: lock uppercase input mode
Press once: unlock the uppercase
In eZiabc (Smartabc) input mode:
Press once: to eZi Abc
Press twice: to eZi ABC

Del key  :
Press: delete one by one
Press and hold: delete one by one quickly

⁽¹⁾ 3000G only. For 3000H, only normal writing method is available for all languages.

20 Telephone warranty.....

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months ⁽¹⁾ from the date of purchase as shown on your original invoice.

Batteries ⁽²⁾ and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months ⁽¹⁾ from the date of purchase as shown on your original invoice.

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories are entitled to a one ⁽¹⁾ month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes any other costs.

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

- ⁽¹⁾ The warranty period may vary depending on your country.
- ⁽²⁾ The life of a rechargeable mobile phone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone during the first six months after purchase and for approximately 200 more recharges.

- 1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your phone is used,
- 2) Connection to any equipment not supplied or not recommended by TCT Mobile Limited,
- 3) Modification or repair performed by individuals not authorised by TCT Mobile Limited or its affiliates or your vendor,
- 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation...

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

In no event shall TCT Mobile Limited or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

2 | Accessories.....

The latest generation of ALCATEL ONE TOUCH GSM mobile phones offers a built-in handsfree feature that allows you to use the telephone from a distance, placed on a table for example. For those who prefer to keep their conversations confidential, an earpiece is also available known as the headset.


1. Charger
2. Battery
3. Stereo headset



Only use your telephone with ALCATEL ONE TOUCH batteries, chargers and accessories in your box.

22 Troubleshooting

Before contacting the service centre, you are advised to follow the instructions below:


- You are advised to fully charge () the battery for optimal operation.
- Avoid storing large amounts of data in your phone as this may affect its performance.
- Use User Data Format to perform phone formatting (to perform User Data format, hold down # while simultaneously pressing the power on/off key). ALL User phone data: contacts, messages and files will be lost permanently.

and carry out the following checks:

My phone cannot switch on

- Check the battery contacts, remove and reinstall your battery, then turn your phone on
- Check the battery power level, charge for at least 20 minutes
- If it still does not work, please use User Data Format to reset the phone ⁽¹⁾

My phone is frozen or has not responded for several minutes

- Restart your phone by pressing and holding the  key
- Remove the battery and re-insert it, then restart the phone
- If it still does not work, please use User Data Format to reset the phone ⁽¹⁾

My phone turns off by itself

- Check that your keypad is locked when you are not using your phone, and make sure power off key is not mis-contacted due to unlocking keypad
- Check the battery charge level
- If it still does not work, please use User Data Format to reset the phone ⁽¹⁾

My phone cannot charge properly

- Make sure you are using an ALCATEL ONE TOUCH battery and the charger from the box
- Clean the battery contact if it's dirty
- Make sure your battery is inserted properly before plugging in the charger
- Make sure that your battery is not completely discharged; if the battery power is empty for a long time, it may take around 20 minutes to display the battery charger indicator on the screen
- Make sure charging is carried out under normal conditions (0°C to +40°C)
- When abroad, check that the voltage input is compatible

My phone cannot connect to a network or "No service" is displayed

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually (see page 40)
- Try connecting at a later time if the network is overloaded


My phone cannot connect to the Internet

- Check that the IMEI number (press *#06#) is the same as the one printed on your warranty card or box
- Make sure that the internet access service of your SIM card is available
- Check your phone's Internet connecting settings
- Make sure you are in a place with network coverage
- Try connecting at a later time or another location

Invalid SIM card

- Make sure the SIM card has been correctly inserted (see page 14,15)
- Make sure the chip on your SIM card is not damaged or scratched
- Make sure the service of your SIM card is available

Unable to make outgoing calls

- Make sure you have dialed a valid number and press the  key
- For international calls, check the country and area codes
- Make sure your phone is connected to a network, and the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not barred outgoing calls (see page 39)
- Make sure that your phone is not in flight mode

Unable to receive incoming calls

- Make sure your phone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not forwarded incoming calls (see page 38)
- Make sure that you have not barred certain calls
- Make sure that your phone is not in flight mode



The caller's name/number does not appear when a call is received

- Check that you have subscribed to this service with your operator
- Your caller has concealed his/her name or number

I cannot find my contacts

- Make sure your SIM card is not broken
- Make sure your SIM card is inserted properly
- Import all contacts stored in SIM card to phone

The sound quality of the calls is poor

- You can adjust the volume during a call by pressing the  key
- Check the network strength 
- Make sure that the receiver, connector or speaker on your phone is clean

I am unable to use the features described in the manual

- Check with your operator to make sure that your subscription includes this service
- Make sure this feature does not require an ALGATEL ONE TOUCH accessory

When I select a number from my contacts, the number cannot be dialed

- Make sure that you have correctly recorded the number in your file
- Make sure that you have inputted the country prefix when calling a foreign country

I am unable to add a contact in my contacts

- Make sure that your SIM card contacts are not full; delete some files or save the files in the phone contacts

My callers are unable to leave messages on my voicemail

- Contact your network operator to check service availability

I cannot access my voicemail

- Make sure your operator's voicemail number is correctly entered in "Messages\Voicemail"
- Try later if the network is busy

The flickering icon is displayed on my standby screen

- You have saved too many short messages on your SIM card; delete some of them or archive them in the phone memory

SIM card PIN locked


- Contact your network operator to obtain the PUK code (Personal Unblocking Key)

I am unable to download new files

- Make sure you have inserted microSD card
- Make sure there is sufficient microSD card memory for your download
- Check your subscription status with your operator

How to make your battery last longer

- Make sure you follow the complete charge time (minimum 3 hours)
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication
- Switch on the backlight upon request

(1)  **User Data Format** ALL user phone data: Contacts, messages and files will be lost permanently. Please store phone data in SIM card before you want to format

ALCATEL is a trademark of Alcatel-Lucent
and is used under license by
TCT Mobile Limited.

All rights reserved © Copyright 2013
TCT Mobile Limited.

TCT Mobile Limited reserves
the right to alter material or technical
specification without prior notice.